



SPEED HUMP MARKING AND SIGNING

NOTES:

1. SAWCUT OR FEATHER GRIND TO KEY IN SPEED HUMP. SEE SECTION A-A.
2. SIGN LOCATIONS SHALL BE VERIFIED BY THE ENGINEER PRIOR TO INSTALLATION.
3. SPEED HUMP CHEVRON MARKING SHALL BE THERMOPLASTIC, HEAT FUSED PREFORMED, 90 MIL., OR EQUAL APPROVED BY THE ENGINEER.
4. FOR A SERIES OF SPEED HUMPS, USE THE ADVISORY SPEED PLAQUE AT ONLY THE FIRST SPEED HUMP IN EACH DIRECTION OF TRAVEL.
5. SPEED HUMP TO BE INSTALLED USING CITY PROVIDED TEMPLATE, 48 HOURS NOTICE REQUIRED.

